Keurig

1. To fill machine, remove the water reservoir from brewer by first removing lid from reservoir, then lifting reservoir straight up and away from brewer (may be tight). Fill to MAX FILL line with fresh water. Replace reservoir on brewer.
2. Press the power switch located on the rear right side of the Brewer. Heating will take approximately 4 minutes and “NOT READY” will be displayed on the control panel. The control panel will display “OPEN HEAD” when ready.

3. Place a mug on the drip tray plate.
4. Lift the silver handle to insert your selected K-Cup. NOTE: Do not remove the foil lid or puncture the K-Cup.
5. All brew size icons will be displayed with the default size shown as a solid mug. To choose a different size, use the buttons. Once a size is chosen, press ‘Brew’.

If the brewer does not brew, lift and relower handle, check water levels and make sure the water reservoir is properly inserted.